


N.12



■ **MODE ON/OFF**


This mode is used to permit watering or prevent any valve from opening. It overrides both manual or programmed valve opening.

Repeatedly press until

this screen (N.12) appears with a blinking cross on the sprinkler. Connect the transmitter to the module and press the key to place the module in the "ON" mode. The cross will disappear. Any programmed or manual irrigation will take place. If you press the key, the module will be placed in the "OFF" mode. A non-blinking cross appears on the sprinkler and all irrigation, either programmed or manual, will be prevented. This mode is useful during rainy weather (rainy weather shutdown). The irrigation program remains stored in the module.

Important: Make sure that the control module is in the "ON" mode before trying to manually open a valve with the field transmitter.

N.13



■ **LOW BATTERY ICON**

a) **Low battery in the field transmitter**


If the battery is low in the field transmitter, this screen (N.13) with the blinking low battery icon will appear after you press . Replace the battery in the field transmitter.

b) **Low battery in the control module**


After you transmit a program

to a module or monitor a program in a module, this screen (N.14) will appear if the battery in the module must be replaced.

N.14



N.15



■ **ERR 1 MESSAGE (N.15)**

If the transmitter is incompatible with the control module, the Err 1 message will be displayed on the LCD. This can happen when a new

Micro 2000 field transmitter is connected to a control module with a date code prior to October 2, 2000.

■ **ERASE PROGRAM DATA IN THE TRANSMITTER**

This function erases all program data (MODE A and MODE B) in the transmitter except current time and day.



Press the keys simultaneously and hold them down for at least 3 seconds.

■ **DAILY OPERATION OF SOLENOIDS**

In order to stop a potential build-up of mineral deposits on the solenoids, Cyclik control modules will ensure that all solenoids open and close at least once every 24 hours, even during a long off-cycle. The Cyclik control modules will cycle all solenoids on and off for no more than 3 seconds, every 24 hours after the last valve closure. Whenever programmed operation is already opening or closing a solenoid within 24 hours, the 3 second anti-mineral cycle will not occur.

**Rain Bird Corporation
Agri-Products Division**
633 W. Foothill Blvd.
Glendora, CA 91741-2469
Phone: (800) 435-5624
Fax: (626) 852-7310

Rain Bird International, Inc.
145 N. Grand Ave.
Glendora, CA 91741-2469
Phone: (626) 963-9311
Fax: (626) 963-4287

www.rainbird.com

Rain Bird. The Intelligent Use of Water.™


® Registered trademark of Rain Bird Corporation

© 2003 Rain Bird Corporation 3/03



CYCLIK™ Micro

■ Programming Guide Mode B



PN L366


CYCLIK™ Micro B

Mode B Quick-Start Programming




Use with a single station control module

■ INSTALL BATTERY


N.1








■ CHOOSE MODE B

Press  if the LCD is blank. Simultaneously press  and  to select MODE B (N.1). Repeat the procedure to move from MODE B to MODE A or vice versa. The selected mode is displayed during 3 seconds, after this, no icon appears on the screen to indicate which mode has been selected.


N.2




■ SET CURRENT TIME

As soon as the battery is connected, the standby screen appears (N.2). The field transmitter can now be programmed. If the screen is blank, press the  key once to activate the field transmitter. Press the  key again. The clock symbol will appear (N.3).  Use the  or  keys to set the current time.


N.3



N.4










■ SET CURRENT DAY

Using the  key to place the square on the current day of the week (N.4). Monday = 1...Sunday = 7 Example: 11:08PM, Wednesday


N.5




■ PROGRAMMING THE TIME WINDOW(S)




Press the  key to display this icon: (N.5)  This screen (N.5) indicates that you must now set the start time of the 1st time window. Use the  and  keys. In this example, the 1st time window starts at midnight. Press the  key to display the word (OF) and use   to select the end of the first time window (N.6).

N.6




N.7







Press the same key  again to access this screen (N.7) if you wish to enter a 2nd time window. Note the "2" at the bottom of the screen. Set the 2nd time window opening and closing times (N.8) as above. If you do now want a 2nd time window, use the  and  keys to display -- -- situated between 11:59 and 12:00 or between 23:59 and 00:00.


N.8



■ SET RUN TIME AND SOAK TIME


Press the  key to display this screen  (N.9) after you finish programming the time window(s). The "ON" indicates that you should now enter the irrigation run time in minutes and seconds in 1-second increments. Use the  and  keys.




N.9






Minimum: 10 seconds
Maximum: 99 minutes


N.10



Next press  to enter the soak time. The "OF" indicates that you should now enter the soak time with the  and  keys (0 to 99 minutes in 1-minute increments) (N.10).

■ TRANSMISSION TO CYCLIK CONTROL MODULES

Connect the field transmitter to the Control Module. Press  to activate the LC screen if it is blank. Press . The transmission icon  will appear for 2 seconds.

Note: If there is a transmission problem (poor connection, dirty connector, lack of battery or dead battery, etc.) you will hear 3 "beeps" and this screen will appear. 


Important: If the blinking battery icon is displayed on the LCD during program transmission, replace the 9V battery in the Cyclik control module.

Note: MODE B operates only with the 1-station Cyclik 2000 control modules. If you transmit MODE B to a multi-station module, only the 1st station will operate.





MANUAL FUNCTIONS

■ MODE B: MANUAL START

N.11



This mode allows you to close or open a valve with the field transmitter without programming a run time. Make sure that the

transmitter is in MODE B. Repeatedly press the  key to access this screen (N.11). Connect the field transmitter to the control module. Press  to open the valve. To close the valve, repeatedly press  to display screen N.11, connect the field transmitter to the module, then press .

Note: When operating in manual, the field transmitter and the control module must be in the same mode (mode A or mode B). If the field transmitter is in a different mode than the control module, the control module will send a signal back and will put the transmitter in the same mode as the control module. If this happens, refer to the manual start instructions for the mode that the control module is in.