



- ① PLANTING
- ② FINISH GRADE
- ③ AMENDED SOIL, DEPTH PER PLANT MATERIAL
- ④ ROOT BOOSTER NET, SEE LEGEND FOR MODEL
- ⑤ SUB-SURFACE DRIPLINE WRAPPED IN ROOT BOOSTER SLEEVE
- ⑥ 6" LANDSCAPE STAKE INSTALLED EVERY 6' ON TUBING. DO NOT PIERCE MATERIAL
- ⑦ UNDISTURBED SOIL

NOTES:

1. PULL NET APART APPROXIMATELY 4-5 TIMES ITS WIDTH AND LAY FLAT ON UNDISTURBED SOIL.
2. PLACE NET DEEP ENOUGH TO LAY BELOW THE ROOTS. COVER WITH SOIL AND BEGIN PLANTING ABOVE THE NET.
3. ROOT BOOSTER COMPLEMENTS IRRIGATION SYSTEMS. THIS DESIGN DETAIL IS INTENDED TO ACCOMPANY THOSE OF THE VARIOUS IRRIGATION APPLICATIONS



## ROOT BOOSTER NET AND SLEEVE PROFILE

N.T.S.