



NOTE:  
 QUICK COUPLER SHALL BE INSTALLED  
 ON A PVC SWING JOINT.  
 ADJUST ANGLE OF SWING JOINT LAY ARM  
 BETWEEN 30° TO 45° TO ALLOW ADEQUATE  
 IMPACT ABSORPTION. TOP SHALL BE FLUSH  
 WITH FINISH GRADE.

# TYPICAL QUICK COUPLING VALVE ON A PVC SWING JOINT

NOT TO SCALE

