



RAIN WATCH INSTALLATION NOTES:

1. RAIN WATCH DEVICES SHALL BE FIELD LOCATED DURING THE STAKING OF THE SYSTEM.
2. THE RAIN BIRD TIPPING BUCKET RAIN CAN (#F89400) SHALL BE LOCATED WITHIN 60' (FT) OF THE CENTRAL EQUIPMENT, OR WITHIN 300' (FT) OF A FIELD CONTROLLER OR DECODER BOX LOCATION.
3. THE RAIN CAN MAY BE MOUNTED TO THE FREEDOM ANTENNA MAST AT THE CENTRAL EQUIPMENT LOCATION, OR MOUNTED ON A PROPERLY ANCHORED 10' X 1 1/4" GALVANIZED STEEL POLE AT A FIELD CONTROLLER OR DECODER BOX LOCATION.
4. PAGE P7171D OR BELDEN 9983 CABLE SHALL BE USED TO CONNECT THE INTEGRATED RAIN CAN CABLE TO THE DECODER DEVICE ON FIELD INSTALLATIONS.
5. THE INTEGRATED 60' RAIN CAN CABLE SHALL BE USED AT THE CENTRAL EQUIPMENT LOCATION.
6. ALL EXPOSED WIRING SHALL BE IN CONDUIT.

RAIN WATCH ANTENNA INSTALLATION DETAIL

NOT TO SCALE

RAIN BIRD