






IQ4 – ESP-LXME2 Setup

The ESP-LXME2 controller is a new "traditionally wired" controller from Rain Bird. It can connect to the IQ4 Cloud system for full central control functionality.

- Works with IQ4-Cloud software (Not compatible with IQ3)
- Contains 40 programs
- Allows two Master Valves (one full MV and one NC/Pump Start functionality)
- Programs like the ESP-LXME controller
- Currently is in Field Test and requires authorization to work with IQ4-Cloud




The Intelligent Use of Water™

ESP-LXME2 with IQ4

Users with existing IQ4 Account


Add a controller

• Controller page -> click on orange circle with + sign to add the controller




Add a controller – Edit settings


- Add Controller page -> enter settings
- Click on Save



- All programming/scheduling is identical to the ESP-LXME controller except:
 - Programs There are 40 programs




- All programming/scheduling is identical to the ESP-LXME controller except:
 - Master Valves There are two master valves
 - MV1 is a fully functional MV with setting for Normally Closed or Normally Closed
 - MV2 is setup as a NC MV/Pump Start operating as a NC master valve



- Updating ESP-LXME2 Firmware:
 - -There are three items to update Front Panel, Output module and NCC cartridge

• To update the firmware, click on the More button above Controller Settings -> select the Update Firmware button. A list of required updates will be shown.



ESP-LXME2 with IQ4

Users without existing IQ4 Account

Registration




- Registration. Enter url:
- 1. https://www.rainbird.com/products/iq4

IQ4 Access for PC







Registration

rainbird.com/products/IQ4

IQ4 Access for **Mobile Device**



IQ4

Modular Multi-Site Central Control

The IQ4 Platform offers state-of-the-art monitoring, programming and control features in an easy to learn user interface. IQ4 provides advanced water management features saving money and time. IQ4 is available in a Cloud-based

| ſ | IQ4 Registration | n |
|---|------------------|---|
| | IQ4 Access | |

After registration you will click IQ4 access

Click to Cre Account.

| RAIN | RD. |
|-----------------------|-----|
| Jsername | |
| Username | |
| assword | |
| Password | |
| Forgot your password? | |
| Remember me | |
| Login | |
| Create Account | |
| <u> </u> | |

Registration


Select ACCEPT for Terms and Conditions

New Account

Existing Users



Postal Code





Create a New

Company Information

Account

Address


--- Select Country


Account Information

- Select either
 - 5. Create New Account
 - 6. (Optional) Existing User (IQ3 User to transfer to IQ4)

The Intelligent Use of Water™

E-mail Confirmation






IQ4 Registration Email confirmation

Thank you for registering with Rain Bird's IQ4 software. Please click on the following link to confirm your email address and complete the registration.


confirm email

Thank you for purchasing Rain Bird irrigation products

The Rain Bird Central Control Team



System is ready for Login access User name & **Password**




The Intelligent Use of Water™

© 2021 Rain Bird Corporation. | 14


Add a controller

• Controller page -> click on orange circle with + sign to add the controller




Add a controller – Edit settings


- Add Controller page -> enter settings
- Click on Save



- All programming/scheduling is identical to the ESP-LXME controller except:
 - Programs There are 40 programs




- All programming/scheduling is identical to the ESP-LXME controller except:
 - Master Valves There are two master valves
 - MV1 is a fully functional MV with setting for Normally Closed or Normally Closed
 - MV2 is setup as a NC MV/Pump Start operating as a NC master valve



- Updating ESP-LXME2 Firmware:
 - -There are three items to update Front Panel, Output module and NCC cartridge

• To update the firmware, click on the More button above Controller Settings -> select the Update Firmware button. A list of required updates will be shown.



Support Questions

Support Questions

For support of the ESP-LXME2 controller:

Doug Closter – <u>dcloster@rainbird.com</u>

For support of IQ4:

Rick Malkin – rmalkin@rainbird.com

RAIN-S BIRD.