


14VH



Ref.	Part Description	14VH
UPPER ASSEMBLY		
3	Fulcrum Kit	177416
1	Fulcrum Pin	(100793)
2	Arm Hood	(117360)
7	Arm Spring Assembly	177521
4	Arm Spring	(100172)
5	Wedge	(111188)
6	Wedge Pin	(116046)
NOZZLES (Specify nozzle size when ordering)		
8	Straight Bore	105780xx
BEARING ASSEMBLY		
9	Bearing Assembly (H Style)	177535
10	Top Seal Washer (Black)	(104183)
11	Metal Top Seal Washer	(100280)
12	Bearing Spring	(105431)
13	Bearing Sleeve (Brass)	177510
14	Bearing Washer (2) (Black)	(104181)
15	Wear Washer	(104696)
16	Bearing Nipple	177516
17	Bearing Washer Kit	177536
10	Top Seal Washer (Black)	(104183)
11	Metal Top Seal Washer	(100280)
12	Bearing Spring	(105431)
14	Bearing Washer (2) (Black)	(104181)
15	Wear Washer	(104696)

Note: Part numbers enclosed in brackets () are not available individually, but may be sold in assemblies or kits.