




ESP-LXME



- 1 Remove jumper wire, if present.**
Retire el cable puente, si lo hay.



- 2 Connect WR2 wires.**
Conecte los cables del sensor WR2.