



- ① IRRIGATION CONTROLLER:
RAIN BIRD IQ ESP–LXMEF SATELLITE CONTROLLER WITH FLOW SMART MODULE AND IQ NCC WiFi CARTRIDGE IN LXMM METAL CABINET WITH OUTSIDE WALL MOUNT. INSTALL CONTROLLER AND CABINET ON WALL PER MANUFACTURER’S RECOMMENDATIONS.
- ② WiFi ANTENNA:
RAIN BIRD IQWFEXTANT WiFi EXTERNAL ANTENNA (FOR USE WITH LXMM METAL CABINET ONLY)
- ③ JUNCTION BOX
- ④ 1–INCH CONDUIT AND FITTINGS TO POWER SUPPLY
- ⑤ POWER SUPPLY WIRE
- ⑥ 2–INCH CONDUIT AND FITTINGS FOR STATION WIRES
- ⑦ MASTER VALVE AND REMOTE CONTROL VALVE WIRES
- ⑧ FLOW SENSOR WIRE (PE 39, 89 OR 54) TO FLOW SENSOR

NOTES:

1. IQ ESP–LXMEF CONTROLLER IS AVAILABLE IN 8– OR 12–STATION BASE MODELS. ADDITIONAL MODULES IN 4–, 8– AND 12–STATION VERSIONS MAY BE ADDED TO BRING THE CONTROLLER UP TO 48 STATIONS MAXIMUM.
2. FOR EASE OF INSTALLATION INTO A CONTROLLER WITH MORE THAN 24 STATIONS, INSTALL A JUNCTION BOX AT THE BASE OF CONTROLLER AND TRANSITION LARGER VALVE AND COMMON WIRES FROM FIELD TO 18 AWG MULTI CONDUCTOR WIRE TO BE USED IN CONTROLLER.
3. USE STEEL CONDUIT FOR ABOVE GRADE AND SCH 40 PVC CONDUIT FOR BELOW GRADE CONDITIONS.
4. PROVIDE PROPER GROUNDING COMPONENTS TO ACHIEVE GROUND RESISTANCE OF 10 OHMS OR LESS.
5. OWNER IS RESPONSIBLE FOR PROVIDING WIRELESS INTERNET SERVICE CAPABLE OF INTERFACING WITH NCC WiFi CARTRIDGE. INSTALL CONTROLLER IN A LOCATION TO MAXIMIZE ANTENNA RECEPTION. CONDUCT A SURVEY OF THE SITE TO ASSURE A VIABLE AND CONSISTENT WiFi CONNECTION BEFORE INSTALLING CONTROLLER.

**IQ ESP-LXMEF SATELLITE CONTROLLER
WITH FLOW SMART MODULE**

N.T.S.

**AND IQ NCC WiFi CARTRIDGE
IN METAL CABINET**

1–12–11

