



- ① TWO-WIRE DECODER CONTROLLER:
RAIN BIRD IQ ESP-LXD SATELLITE TWO-WIRE DECODER CONTROLLER WITH IQ CONNECTION MODULE AND IQ NCC WiFi CARTRIDGE IN LXMM METAL CABINET WITH OUTSIDE WALL MOUNT. INSTALL CONTROLLER AND CABINET ON WALL PER MANUFACTURER'S RECOMMENDATIONS.
- ② WiFi ANTENNA:
RAIN BIRD IQWFEXTANT WiFi EXTERNAL ANTENNA (FOR USE WITH LXMM METAL CABINET ONLY)
- ③ JUNCTION BOX
- ④ 1-INCH CONDUIT AND FITTINGS TO POWER SUPPLY
- ⑤ POWER SUPPLY WIRE
- ⑥ 1-INCH CONDUIT AND FITTINGS FOR COMMUNICATION CABLE TO CLIENT SATELLITE CONTROLLERS
- ⑦ PE-CABLE OR Y-CABLE FOR EXTERNAL RADIO TO CLIENT SATELLITE CONTROLLERS
- ⑧ 2-INCH CONDUIT AND FITTINGS FOR TWO-WIRE CABLE
- ⑨ MAXICABLE TWO-WIRE PATH TO DECODERS
USE A DIFFERENT CABLE JACKET COLOR FOR EACH PATH

NOTES:

- 1. IQ ESP-LXD CONTROLLER COMES WITH 50 STATIONS AVAILABLE. TWO ADDITIONAL 75 STATION ESPLXD-SUM75 MODULES MAY BE ADDED TO EXPAND THE CONTROLLER UP TO 200 TOTAL STATIONS.
- 2. USE STEEL CONDUIT FOR ABOVE GRADE AND SCH 40 PVC CONDUIT FOR BELOW GRADE CONDITIONS.
- 3. PROVIDE PROPER GROUNDING COMPONENTS TO ACHIEVE GROUND RESISTANCE OF 10 OHMS OR LESS.
- 4. OWNER IS RESPONSIBLE FOR PROVIDING WIRELESS INTERNET SERVICE CAPABLE OF INTERFACING WITH NCC WiFi CARTRIDGE. INSTALL CONTROLLER IN A LOCATION TO MAXIMIZE ANTENNA RECEPTION. CONDUCT A SURVEY OF THE SITE TO ASSURE A VIABLE AND CONSISTENT WiFi CONNECTION BEFORE INSTALLING CONTROLLER.

IQ ESP-LXD SATELLITE TWO-WIRE DECODER CONTROLLER WITH IQ CONNECTION MODULE

N.T.S.

AND IQ NCC WiFi CARTRIDGE IN METAL CABINET

1-10-11

D