


RAIN WATCH™ INSTALLATION NOTES:

1. RAIN WATCH DEVICES SHALL BE FIELD LOCATED DURING THE STAKING OF THE SYSTEM.
2. THE RAIN CAN MAY BE MOUNTED TO THE FREEDOM ANTENNA MAST AT THE CENTRAL EQUIPMENT LOCATION, OR MOUNTED ON A PROPERLY ANCHORED 10' X 1 1/4" GALVANIZED STEEL POLE (AS SHOWN), OR PROPERLY ANCHORED 4" X 4" PRESSURE TREATED POST (NOT SHOWN).
3. THE RAIN CAN SHALL BE CONNECTED TO A RAIN BIRD IC-IN INSTALLED IN A VALVE BOX AS SPECIFIED.
4. INTEGRATED 60' RAIN CAN CABLE SHALL BE ROUTED THRU THE POLE AND INTO THE ADJACENT SPLICE BOX ON FIELD LOCATED INSTALLATIONS. THE INTEGRATED RAIN CABLE IS NOT RATED FOR DIRECT BURIAL AND MUST BE ROUTED THROUGH CONDUIT IN DIRECT BURY APPLICATIONS.
5. ALL EXPOSED WIRING SHALL BE IN CONDUIT.



RAIN WATCH™ FIELD INSTALLATION DETAIL

NOT TO SCALE

RAIN BIRD.