


NOTES:

1. AT ALL SPLICE LOCATIONS, PROVIDE SUFFICIENT SLACK TO ALLOW THE SPLICE TO BE RAISED A MINIMUM OF 24" (IN.) ABOVE GRADE FOR INSPECTION.
2. ALL POWER CABLE SHALL HAVE A MINIMUM OF 24" (IN.) OF COVER.
3. CLEARLY MARK ON TAG WHERE SUPPLY CABLE ORIGINATES FROM (EX: FROM 8th HOLE) AND EACH OUTGOING CABLE GOES TO (EX: TO SATELLITE #4) IN AN OUTWARD BOUND DIRECTION FROM THE POWER SOURCE.
4. AT SATELLITE, LOCATE POWER CABLE SPLICE BOX WITHIN 24" (IN.) OF CONCRETE BASE. USE 10/3 TRAY CABLE FROM SPLICE BOX TO THE FIRST SATELLITE OF A CONTROLLER CLUSTER. WIRE ADDITIONAL CONTROLLERS AT LOCATION IN SERIES FROM FIRST CONTROLLER.
5. APPLY UL LISTED COLORED ELECTRICAL TAPE TO POWER CABLE CONDUCTORS WHERE CABLE DAYLIGHTS.



POWER CABLE SPLICE BOX AT CONTROLLER

NOT TO SCALE